

# Program Editor "Pro" Tool

Press the **OPT** button, touch the "Program" menu button and then select the "Program Editor" option to show the view. In this view you can enter or edit a program in a convenient way.

The screenshot shows the Program Editor interface with the following callouts:

- Program line index:** Points to the first column of the program list.
- Program instruction:** Points to the instruction text in the second column.
- Dynamic keypad to enter program instructions:** Points to the grid of function and numeric keys.
- Toggle "F" functions in the Keyboard:** Points to the yellow 'F' button.
- Toggle "G" functions in the Keyboard:** Points to the blue 'G' button.
- Select to Load, Save, Insert, Delete or Clear:** Points to the grey 'Action' button.
- Close the view and updates program memory:** Points to the yellow 'Done' button.

Line Index	Instruction
074	16 CHS
075	44 20 3 STO X 3
076	34 $x \leq y$
077	45 5 RCL 5
078	43 35 g x=0
079	43,33,089 g GTO 0 8 9
080	45 6 RCL 6
081	45 3 RCL 3
082	45 4 RCL 4
083	20 X
084	44 6 STO 6
085	35 CLX

The dynamic keypad includes the following keys:

- Row 1: n, i, PV, PMT, FV, CHS
- Row 2:  $y^x$ ,  $1/x$ , %T,  $\Delta\%$ , %, EEX
- Row 3: R↓,  $x \leq y$ , 7, 8, 9, ÷
- Row 4: STO, RCL, 4, 5, 6, x
- Row 5: R/S, CLX, 1, 2, 3, -
- Row 6: ENTER (=), 0, .,  $\Sigma+$ , +
- Bottom Row: Action ►, F, G, Done

The editor has three areas: the program listing, the keypad to enter instructions and the actions buttons.

## Data Listing:

- Shows the current content of the program memory.
- Touch a program line of the list to select it. The row must exist to allow the selection.

## Keypad:

- The keyboard contains all the programmable instructions available in the calculator.
- The instruction is actually entered in the program memory when a complete key sequence is finished.

## Action Buttons:

[Action ►]	Shows actions that affects the whole list. Save the program to file, Load a previous saved program, Insert or Delete a program line, and Clear the whole program.
[F]	Toggles the keyboard to show the “F” functions keys.
[G]	Toggles the keyboard to show the “G” functions keys.
[Done]	Close the editor and set the program line counter to 0.